



1. CONNECT TRACER WIRE TO EXISTING TRACER WIRE AT EXISTING CONNECTIONS
2. THE CONTRACTOR SHALL UTILIZE A TRENCH BOX OR OTHER OSHA APPROVED SHORING METHODS TO MINIMIZE SURFACE RESTORATION REQUIREMENTS

NOT TO SCALE

CITY OF STURGIS

STANDARD DETAILS

PIPE ENCASEMENT

AUG 2017

11-1